



Tru Cure Rust Remover & Converter Instructions

FOR HEAVY RUST: Wire brush the surface to remove any loose scale. Remove any grease present. Apply Tru Cure with a sprayer, nylon brush, sponge, or cloth. Allow time for rust to dissolve (usually in 30 minutes or less) and then allow to dry thoroughly. To achieve a smoother surface, wipe the dissolved residue with a clean cloth moistened with Tru Cure. Chrome and painted surfaces should be clean and dry. Tru Cure will dry and leave behind a very thin film. Do not rinse or wipe off.

FINISHING: IT IS IMPORTANT THAT TRU CURE IS THOROUGHLY DRIED BEFORE APPLYING PAINT. IF SURFACE IS WET OR DAMP, PAINT MAY BUBBLE.

When Tru Cure is dried thoroughly, it forms a tough primed surface. This primed surface bonds well with most paints, with or without additional primers. For surfaces to be waxed or polished, dissolve surface rust with Tru Cure, wipe to a very thin film, and apply wax or polish immediately. Covers up to 8 square feet per ounce.

NOTICE: PM Industries' liability under any expressed or implied warranty is limited to the replacement of this product if proved defective and does not include labor or other consequential damages. PM Industries is not liable for items damaged due to improper storage. The suitability of the product for any extended use shall be solely up to the user.

For more information and reordering, visit

www.mastercoatusa.com

or call

1-800-833-8933 9am-5pm EST

PM Industries, 939 Westbrook Road, West Milford NJ 07480

